Speaker Stand Leg Orientation

Please ensure that when attaching legs to the speaker stand they are oriented as shown.

Legs will face diagonal and out from the corners. The leg plates are positioned as shown in photo below.

These legs are indiviually adjustable from the rubber tip. Screws for assembly are provided.



